


# FRIGIDAIRE

All about the

# Use & Care

of your Refrigerator



## TABLE OF CONTENTS

|                                    |    |                                      |    |
|------------------------------------|----|--------------------------------------|----|
| Important Safety Instructions..... | 2  | Storage Features.....                | 14 |
| Feature Overview .....             | 4  | Storing Food and Saving Energy ..... | 15 |
| Installation .....                 | 5  | Care and Cleaning .....              | 16 |
| Interior Lighting .....            | 9  | Before You Call .....                | 18 |
| Controls.....                      | 10 | Major Appliance Warranty .....       | 20 |
| Changing the Filter .....          | 13 |                                      |    |

# IMPORTANT SAFETY INSTRUCTIONS



## WARNING

Please read all instructions before using this refrigerator.

## Safety Instructions

- DO NOT store or use gasoline, or other flammable liquids in the vicinity of this or any other appliance. Read product labels for warnings regarding flammability and other hazards.
- DO NOT operate the refrigerator in the presence of explosive fumes.
- Remove and discard any spacers used to secure the shelves during shipping. Small objects are a choke hazard to children.
- Remove all staples from the carton. Staples can cause severe cuts, and also destroy finishes if they come in contact with other appliances or furniture.

## Safety Definitions

 This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



## DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



## WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



## CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



## IMPORTANT

IMPORTANT indicates installation, operation or maintenance information which is important but not hazard-related.



## Installation Checklist

### Doors

- Handles are secure and tight
- Door seals completely to cabinet on all sides
- Refrigerator door is level across the top

### Leveling

- Refrigerator is level, side-to-side and tilted 1/4" (6mm) front-to-back
- Kick plate is properly attached to refrigerator
- Cabinet is setting solid on all corners

### Electrical Power

- House power turned on
- Refrigerator plugged in

### Final Checks

- Shipping material removed
- Fresh food temperatures set
- Crisper humidity controls set
- Registration card sent in
- Anti-tip bracket installed

## Child Safety

Destroy or recycle the carton, plastic bags, and any exterior wrapping material immediately after the refrigerator is unpacked. Children should **NEVER** use these items to play. Cartons covered with rugs, bedspreads, plastic sheets or stretch wrap may become airtight chambers, and can quickly cause suffocation.

# IMPORTANT SAFETY INSTRUCTIONS

## Proper Disposal of Refrigerator or Freezer

### Risk of child entrapment


Child entrapment and suffocation are not problems of the past. Junked or abandoned refrigerators or freezers are still dangerous – even if they will sit for “just a few days”. When disposing of an old refrigerator or freezer, please follow the instructions below to help prevent accidents.

### Proper Disposal of Refrigerators/Freezers

We strongly encourage responsible appliance recycling/disposal methods. Check with the utility company or visit [www.energystar.gov/recycle](http://www.energystar.gov/recycle) for more information on recycling an old refrigerator.

### Before disposing of an old refrigerator/freezer:

- Remove doors.
- Leave shelves in place so children may not easily climb inside.
- Have refrigerant removed by a qualified service technician.



## IMPORTANT

To disconnect power to the unit, unplug the unit or switch the breaker that supplies power to the unit to the off position.


## Electrical information

- The refrigerator must be plugged into its own dedicated 115 Volt, 60 Hz., 15 Amp, AC only electrical outlet. The power cord of the appliance is equipped with a three-prong grounding plug for protection against electrical shock hazards. It must be plugged directly into a properly grounded three prong receptacle. The receptacle must be installed in accordance with local codes and ordinances. Consult a qualified electrician. Avoid connecting refrigerator to a Ground Fault Interrupter (GFI) circuit. Do not use an extension cord or adapter plug.
- If the power cord is damaged, it should be replaced by an authorized service technician to prevent any risk.
- Never unplug the refrigerator by pulling on the power cord. Always grip the plug firmly, and pull straight out from the receptacle to prevent damaging the power cord.
- Unplug the refrigerator before cleaning and before replacing a light bulb to avoid electrical shock.
- Performance may be affected if the voltage varies by 10% or more. Operating the refrigerator with insufficient power can damage the compressor. Such damage is not covered under the warranty.
- Do not plug the unit into an electrical outlet controlled by a wall switch or pull cord to prevent the refrigerator from being turned off accidentally.

### Grounding type wall receptacle



**Do not, under any circumstances, cut, remove, or bypass the grounding prong.**



Power cord with 3-prong grounded plug


# FEATURE OVERVIEW

## Understanding Features and Terms


Your Frigidaire refrigerator is designed for optimal convenience and storage flexibility. The illustration below is provided to assist you with familiarizing yourself with product features and terminology.

### NOTE

Features may vary according to model.



## Tools Necessary:



This Use & Care Guide provides general operating instructions for your model. Use the refrigerator only as instructed in this Use & Care Guide. Before starting the refrigerator, follow these important first steps.

## Location

- **Getting through narrow spaces:** If your refrigerator will not fit through an entrance area, you can remove the doors. Check by first measuring the entrance. See **DOOR REMOVAL** section.
- Choose a place that is near a grounded electrical outlet. **Do Not** use an extension cord or an adapter plug.
- If possible, place the refrigerator out of direct sunlight and away from the range, dishwasher or other heat sources.




## CAUTION

**DO NOT** install the refrigerator where the temperature will drop below 55°F (13°C) or rise above 110°F (43°C). The compressor will not be able to maintain proper temperatures inside the refrigerator.

**DO NOT** block the kick plate on the lower front of your refrigerator. Sufficient air circulation is essential for the proper operation of your refrigerator.

## Kick Plate Removal

To remove the kick plate, use a Phillips head screwdriver and remove the two screws holding the kick plate to the cabinet. Then pull the kick plate away from the unit.



**Kick Plate Removal**

## Door Removal




## CAUTION

Doors are heavy. Two people are recommended to remove or replace the door assembly from the cabinet.

If door must be removed:

1. Ensure the unit is unplugged, or switch the breaker that supplies power to the unit to the off position.
2. Remove the plastic top hinge cover.



3. Hold the door in place while removing the top hinge from the cabinet.
4. Remove the 2-3/8" hex head screws from the top hinge with a wrench or socket.
5. Lift the door upwards and pull up and away from the cabinet until free of the bottom hinge pin mounted on the front of the cabinet.



## CAUTION

Be sure door is set aside in a secure position where it cannot fall and cause personal injury, nor damage to the door or handle.

6. To replace the door, reverse steps 1-5 and securely tighten all screws to prevent hinge slippage.

# INSTALLATION


## Installation

Installation clearances:

- Allow the following clearances for ease of installation, proper air circulation, and plumbing and electrical connections:  
Sides -  $\frac{3}{8}$ "  
Top and Back - 1"
- Allow for trim kit if it is to be installed with the unit.

### NOTE

If your refrigerator is placed with the door hinge side against a wall, you may have to allow additional space so the door can be opened wider.




## Anti-Tip Installation



### WARNING

The anti-tip bracket must be installed to prevent the unit from tipping over. Failure to do so may result in injury or property damage.

## Components:



1. Follow this Use & Care Guide for unit installation, dimensions, and guidelines.
2. Be sure to level the unit before installation (see "Leveling" in **Installation** section).
3. Find anti-tip bracket, 4 screws, and 4 anchor screws included inside the components bag.
4. Identify a stud in the wall, behind where the unit will be placed, and make a mark on the wall (see Figure 1). If no stud is present behind where the hole is marked, go to step 6.




Figure 1

5. Align one of the center holes of the bracket with the stud. If the bracket extends past the edge of the unit, use a different stud or proceed with instruction 6 (see Figure 2).

### Bracket alignment




Figure 2

6. Measure the distance from the floor to the top back edge of the unit and add  $\frac{1}{8}$  of an inch.
7. Place the bracket against the wall and align the bottom face of the bracket with the measured height from step 6. Make sure one of the center holes is aligned with the mark made in step 4, and confirm the bracket is in the proper orientation (see Figures 1 and 2). Level the bracket.
8. Hold the bracket where the wall is marked for the stud and mark the 2 corner holes and any 2 center holes of the bracket on the wall. Be sure a center hole location is aligned with the vertical stud line made in step 4 (see Figure 3).




Figure 3

9. Remove bracket.
10. Using a Phillips screw driver, push 4 drywall anchors into the marked corner holes and center hole locations with no stud behind them until the threads touch. Screw the anchors clockwise until firm, and then screw  $\frac{1}{4}$  turn more.
11. Realign the bracket on top of the hole location and screw the 4 screws into the anchors or directly into the wall if a stud is present. Screw clockwise until firm, and then screw  $\frac{1}{4}$  turn more.
12. Push the unit to its location, 1 inch away from the wall (see Figure 4).





Figure 4


## Door Handle Mounting Instructions

1. Remove handle and any other protective packaging.
2. Position refrigerator handle end caps over upper and lower pre-installed shoulder bolts (A) that are fastened into door, ensuring the holes for the set screws are facing towards the outside of door if a single unit installation or the freezer door (if installing the matching freezer).
3. While holding handle firmly against door, fasten upper and lower Allen set screws (B) with supplied Allen wrench.
4. Repeat steps 2 and 3 to install freezer handle (if installing the matching freezer). Ensure the holes for the set screws are facing towards the refrigerator door.

### Frigidaire Professional®



### Single Unit Installation



**Ensure Handle Set Screws are Facing Each Other with Doors Closed.**

### Matching Refrigerator and Freezer Door Handle Installation

#### NOTE

All set screws should be tightened and sub-flush (Allen set screw should be seated just below the surface of the end cap) of handle end cap. The end caps should be drawn tight to refrigerator door with no gaps.

# INSTALLATION

## Leveling

The refrigerator must have all leg levelers resting firmly on a solid floor.

The floor must be strong enough to support a fully loaded refrigerator.

It is VERY IMPORTANT for your refrigerator to be level in order to function properly. If the refrigerator is not leveled during installation, the door may be misaligned and not close or seal properly, causing cooling, frost or moisture problems.

### To Level the Refrigerator:

While unit is lying on its back, note the location of the 4 leg levelers installed at each corner. These leg levelers will be used to level the refrigerator and to adjust the height. Use a carpenter's level to level the refrigerator from front to back and side to side. Adjust the plastic leveling feet in front,  $\frac{1}{2}$  bubble higher, so that the door closes easily when left halfway open.

### Leveling Instructions for Matching Refrigerator / Freezer Pair:

- Level door of first unit using all four levelers and slide unit into place. Recheck for levelness and adjust if necessary.
- Measure distance from floor to bottom of door on first unit. Adjust and level second unit so door height matches.

### Leg Level Adjustments:

- One full turn of all four leg levelers will raise door  $\frac{5}{32}$ ".
- Slide second unit into place leaving a minimum gap of  $\frac{3}{16}$ " between units for door swing clearance.
- This last step may require at least one extraction of the second unit to properly align units in a "built-in" application.

### Leveling Door with Adjustable Hinge

Use the lower hinge adjustment to fine tune the door height and for final cabinet spacing. Use a  $\frac{7}{16}$ " socket or wrench to adjust the screw at the bottom of the lower hinge.

### Adjusting Doors for Matching Refrigerator / Freezer Pair

The doors may also be adjusted side to side with the slotted hinge for aligning the doors parallel to each other. Loosen the 3 screws with a  $\frac{3}{8}$ " wrench. Shift the doors until parallel, and then retighten the screws securely. (See Figure 2.)

### Lower Hinge Adjustment for Leveling the Doors of the Matching Refrigerator / Freezer Pair

To level the doors using the adjustable lower hinge (some models):

1. If the refrigerator door is lower than the freezer door, raise the refrigerator door by turning the adjustment screw clockwise using a  $\frac{7}{16}$ " socket wrench. (See Figure 2.)
2. If the freezer door is lower than the refrigerator door, raise the freezer door by turning the adjustment screw clockwise using a  $\frac{7}{16}$ " socket wrench. (See Figure 2.)




Figure 2

## Interior Lighting Control


The interior lighting comes on automatically when the door is opened.

## SHOWCASE Mode Lighting

The interior lights can be placed in a SHOWCASE mode. In this mode the interior lights remain on for approximately 2 hours after the door is closed.

**To enable the SHOWCASE mode**, open the door, press and release the smaller gray switch next to the large gray switch located at the bottom left side of the cabinet front. After closing the door, the interior lights will remain on.


**To disable the SHOWCASE mode anytime before the 2 hours expires**, open the door, press and release the smaller gray switch, and close the door. After closing the door, the interior lights will turn off.




## LED Lighting

### To Replace LED Lights:

1. Unplug the power cord.
2. Remove light cover by pushing up and out.
3. Hold the LED cover with one hand and pull the connector with the other hand while pressing the connector latch.
4. Replace LED light and snap in place assuring the light is facing in toward the unit (inside fresh food).



**LED Light  
Removal**



**LED Light  
Harness Removal**

### **NOTE**

LED lights are in series, so if one is bad or unplugged, several lights may not light up.

# CONTROLS

## Setting the PRO-SELECT™ Electronic Control

### Cool Down Period

For safe food storage, allow 4 hours for refrigerator to cool down completely. The refrigerator will run continuously for the first several hours.

### Pro-Select™ Electronic Control

The Pro-Select™ Electronic Control is located inside the refrigerator. Temperature is factory preset to provide satisfactory food storage temperatures. After 24 hours, gradually adjust the temperature in small increments, allowing the temperature to stabilize. However, the temperature control is adjustable to provide a range of temperatures for your personal satisfaction.



To adjust the temperature setting, press the UP (▲) key for warmer temperature and DOWN (▼) key for colder temperature on the control panel. Allow several hours for the temperature to stabilize between adjustments. The refrigerator can be adjusted between 33°F (1°C) and 46°F (8°C). By pressing the TEMP MODE key, the temperature display will toggle between °F and °C.

To turn the refrigerator OFF, press the UP (▲) key until the warmest temperature setting of 46°F (8°C) shows in the display. Then press the UP (▲) key 3 times within 3 seconds to turn the refrigerator OFF. The display will then show "OF". To turn the unit back ON, press the DOWN (▼) key 3 times within 3 seconds. The control will then display "46°F (8°C)" and may be adjusted to the desired temperature.

## PRO-SELECT™ Electronic Control Features

### Replace Air Filter

When the "REPLACE AIR FILTER" LED is illuminated yellow, the air filter needs to be replaced. The control will signal for air filter replacement after 3600 hours of refrigerator operation. After replacing the air filter, reset the air filter timer by pressing the AIR FILTER key for 3 seconds. The "REPLACE AIR FILTER" LED will be illuminated green for 3 seconds, confirming a timer reset.



### Control Lock

To disable the keypads on the control, begin by pressing the CONTROL LOCK key for 3 seconds until "LO" is displayed for 1 second. With the control locked, when keys are pressed on the control panel, "LO" will be displayed. To unlock the control, press the CONTROL LOCK key for 3 seconds. The display will show "UL" for one second.



## Power Fail

The POWER FAIL indicator light informs you that due to a power failure, the cabinet temperature exceeded 55°F (13°C). If the power failure lasted more than 1 hour, the display alternates between showing the power failure duration (Hours and DURATION LED illuminate in the display) and the cabinet temperature (°F or °C illuminates) every 1/2 second. This safety feature will aid in determining what food spoilage action to take.


The Power Fail indicator light and duration display can be turned off by pressing Alert Reset.



## Sabbath Mode

The Sabbath mode is a feature that disables portions of the refrigerator and its controls, interior lights in accordance with observance of the weekly Sabbath and religious holidays within the Orthodox Jewish community.

Set the electronic control in Sabbath mode. To initiate or exit Sabbath Mode, simultaneously press and hold the CONTROL LOCK and TEMP MODE keys for 3 seconds. Then "Sb" will be displayed on the control panel indicating that the unit is in Sabbath mode.



In the Sabbath mode, the High Temp alarm is active for health reasons. For example, if the door is left ajar the High Temp alarm is activated. The refrigerator will function normally once the door is closed without any violation of the Sabbath/holidays. The High Temp alarm is permitted when the cabinet temperature is outside the safe zone for 20 minutes. The alarm silences itself after 10 minutes while the High Temp icon stays lit until the Sabbath mode is exited.



For further assistance, guidelines of proper usage and a complete list of models with the Sabbath feature, please visit the web at <http://www.star-k.org>.

The unit stays in Sabbath mode after a power failure recovery. It must be deactivated with the buttons on the control panel.

# CONTROLS

## Alerts

There are 4 possible conditions that will cause the alert tone to sound.

### High Temp Alert

If the temperature inside the cabinet exceeds 55°F (13°C), the HIGH TEMP LED will illuminate, and after 1 hour, the HIGH TEMP Alarm will sound with 4 short beeps every ½ second, and the cabinet temperature is shown in the display. The LED and temperature alert will remain active until the cabinet temperature is below 55°F (13°C).



The audible alert can be turned off by pressing Alert RESET key.

### Door Ajar Alert

This alert will sound to alert you that the door has been open for 5 minutes or more. The DOOR AJAR LED will illuminate and the audible alert will sound until the door is closed.

The audible alert can be turned off by pressing the Alert RESET key or by closing the door. If the door is ajar for 15 minutes, the interior light will turn off.

### Temp Error Alert

The sensor alert signals you that a problem exists with a temperature sensor. The audible alarm will sound after 1 hour and the display will alternate between "E8" or "E9" and 33°F (1°C) at ½ second intervals. The control will then enter a mode that runs the refrigerator in a manner that maintains the factory set cabinet temperature.

The audible alert can be turned off by pressing the Alert RESET key.

### Stuck Key Alert

The stuck key alert will sound if the control reads a keypress for longer than 30 seconds. The audible alert will sound and will be limited to one minute and will stop automatically. The display will alternate between "E7" and 33°F (1°C) at ½ second intervals. The control will then enter a mode that runs the refrigerator in a manner that maintains the factory set cabinet temperature until the condition is resolved.

The audible alert can be turned off by pressing the Alert RESET key.


# CHANGING THE FILTER

## PureAir Ultra Filtration System


Your new PureAir Ultra Filtration System is packaged during shipment with your bottle caddy, located in the fresh food section of your appliance. The air filter cover is located on the upper right side of the control box. In general, you should change the air filter with Part Number "PAULTRA" every 6 months to ensure optimal filtering of appliance odors. The replacement air filter can be purchased on the Frigidaire website (<http://frigidaire.stores.yahoo.net>) or call toll free in the U.S. and Canada: 1-800-599-7569. Your electronic control is equipped with a Replace Air Filter indicator to remind you to change your filter.

### To Install Or Replace The Air Filter

1. Pull down on the front of the PureAir Ultra Filtration System cover to release the hinged bottom cover.
2. Allow bottom cover to swing open and then remove the old filter and discard it.
3. Unpackage the new filter and place it inside the hinged bottom cover of the housing.
4. Push the hinged bottom cover upward until the tab snaps into closed position.



**Open Air Filter Cover**



**Remove Air Filter**



# STORAGE FEATURES

## Glass Shelves

Multi-position adjustable slide out glass shelves can be moved to any position for larger or smaller packages. The shipping spacers that stabilize the shelves for shipping may be removed and discarded.


### To Adjust The Shelves

1. Lift front edge up.
2. Pull shelf out.
3. Replace the shelf by inserting the hooks at rear of the shelf into the wall bracket. Lower the shelf into the desired slots and lock into position.



## Deli Drawer

This model is equipped with a Deli Drawer for storage of luncheon meats, spreads, cheeses, and other deli items.




## Crisper Drawer With Adjustable Dividers

The crisper drawer, located at the bottom of the refrigerator interior, is designed for storing fruits, vegetables, and other fresh produce. Wash items in clean water and then remove excess water before placing them in the crisper. Items with strong odors or high moisture content should be wrapped before storing. Dividers may be adjusted for different size items within the crisper.


## Crisper humidity control

Crisper drawers include a sliding control for adjusting the humidity inside the crisper. Leafy vegetables keep best when stored with the Humidity Control set on Higher Humidity. Fresh fruits keep best when stored with the Humidity Control set on Lower Humidity.




## To remove the Crisper Drawer or Deli Drawer:

1. Remove the glass cover from the drawer to be removed.
2. With both hands, lift up on the front of the drawer until it releases from the side supports.
3. Carefully remove the drawer from the refrigerator.



## NOTE

Leafy vegetables keep best when stored with the humidity control set on HIGH HUMIDITY, or in a drawer without a humidity control. This keeps incoming air to a minimum and maintains maximum moisture content.





## Full Width Gallon Bin

The full width gallon bin is especially designed to hold gallon-sized containers like milk gallons.

## Shallow Width Door Bin

The shallow width door bin is designed to hold tall slim bottles.



## Bottle Caddy

The innovative design of the bottle caddy allows storing bottles of wine or soft drink bottles.

# STORING FOOD AND SAVING ENERGY

## Ideas for Storing Foods

### Fresh Food Storage

- Keep the fresh food compartment between 34°F and 40°F with an optimum temperature of 37°F.
- Avoid overcrowding the refrigerator shelves, which reduces air circulation and causes uneven cooling.

### Fruits and Vegetables

- Store fruits and vegetables in crisper drawers, where trapped moisture helps preserve food quality for longer time periods.

### Meat

- Wrap raw meat and poultry securely so leakage and contamination of other foods or surfaces does not occur.

## Ideas for Saving Energy

- Locate the appliance in the coolest part of the room, out of direct sunlight, and away from heating ducts or registers. Do not place the unit next to heat-producing appliances such as a range, oven, or dishwasher. If this is not possible, a section of cabinetry or an added layer of insulation between the two appliances will help the unit operate more efficiently.
- Level appliance so that the door closes tightly.
- Refer to the "SETTING THE TEMPERATURE CONTROL" section for the suggested temperature control settings.
- Do not overcrowd the unit or block cold air vents. Doing so causes the appliance to run longer and use more energy.
- Cover foods and wipe containers dry before placing them in the appliance. This cuts down on moisture build-up inside the unit.
- Organize the appliance to reduce door openings. Remove as many items as needed at one time and close the door as soon as possible.

# CARE AND CLEANING

## Care & Cleaning Tips

Keeping the refrigerator clean maintains its appearance and prevents odor build-up. Wipe up any spills immediately and clean at least twice a year.



### NOTE

Do not use abrasive cleaners such as window sprays, scouring cleansers, flammable fluids, cleaning waxes, concentrated detergents, bleaches, or cleansers containing petroleum products on plastic parts, interior doors, gaskets, or cabinet liners. Do not use scouring pads or other abrasive cleaning materials.

- Never use metallic scouring pads, brushes, abrasive cleaners, or strong alkaline solutions on any surface.
- Never use CHLORIDE or cleaners with bleach to clean stainless steel.
- Do not wash any removable parts in a dishwasher.



### NOTE

When setting temperature controls to turn off cooling, power to lights and other electrical components will continue until the power cord is unplugged from the wall outlet.

- Always unplug the electrical power cord from the wall outlet before cleaning.
- Remove adhesive labels by hand. Do not use razor blades or other sharp instruments which can scratch the appliance surface.
- Do not remove the serial plate. Removal of the serial plate voids the warranty.
- Before moving refrigerator, raise the anti-tip brackets so the rollers will work correctly. This will prevent the floor from being damaged.

Refer to the guide on the next page for details on caring and cleaning specific areas of refrigerator.



### CAUTION

- Pull the refrigerator straight out to move it. Shifting it from side to side may damage flooring. Be careful not to move the refrigerator beyond the plumbing connections.
- Damp objects stick to cold metal surfaces. Do not touch refrigerated surfaces with wet or damp hands.

## Vacation and moving tips

| Occasion               | Tips   |
|------------------------|--|
| <b>Short Vacations</b> | <ul style="list-style-type: none"><li>• Leave refrigerator operating during vacations of three weeks or less.</li><li>• Use all perishable items from refrigerator compartment.</li></ul>  |
| <b>Long Vacations</b>  | <ul style="list-style-type: none"><li>• Remove all food.</li><li>• Turn the cooling system off (see "Controls" section for location of On/Off button) and disconnect power cord.</li><li>• Clean interior thoroughly.</li><li>• Leave both doors open to prevent odors and mold build-up. Block doors open if necessary.</li></ul>   |
| <b>Moving</b>          | <ul style="list-style-type: none"><li>• Remove all food.</li><li>• Secure all loose items such as base panel, baskets, and shelves by taping them securely in place to prevent damage.</li><li>• If using a handcart, load from the side.</li><li>• Adjust rollers all the way up to protect them during sliding or moving.</li><li>• Pad cabinet to avoid scratching surface.</li></ul> |

# CARE AND CLEANING

| Care & Cleaning Tips  |   |   |
|---|---|---|
| Part  | What To Use   | Tips and Precautions  |
| <b>Interior &amp; Door Liners</b>                           | <ul style="list-style-type: none"> <li>• Soap and water</li> <li>• Baking soda and water</li> </ul>                       | Use two tablespoons of baking soda in one quart of warm water. <b>Be sure to wring excess water out of sponge or cloth before cleaning around controls, light bulb or any electrical part.</b>  |
| <b>Exterior Glass Door</b>                                  | <ul style="list-style-type: none"> <li>• Soap and water</li> </ul>  | Use mild soap with water and soft cloth to clean. Rinse well and wipe dry with a clean, soft cloth.   |
| <b>Door Gaskets</b>   | <ul style="list-style-type: none"> <li>• Soap and water</li> </ul>  | Wipe gaskets with a clean soft cloth.   |
| <b>Drawers &amp; Bins</b>                                   | <ul style="list-style-type: none"> <li>• Soap and water</li> </ul>  | Use a soft cloth to clean drawer runners and tracks.  |
| <b>Glass Shelves</b>  | <ul style="list-style-type: none"> <li>• Soap and water</li> <li>• Glass cleaner</li> <li>• Mild liquid sprays</li> </ul> | Allow glass to warm to room temperature before immersing in warm water.   |
| <b>Exterior &amp; Handles</b>                               | <ul style="list-style-type: none"> <li>• Soap and water</li> <li>• Non Abrasive Glass Cleaner</li> </ul>                  | Do not use commercial household cleaners containing ammonia, bleach or alcohol to clean handles or exterior. <b>DO NOT use a dry cloth to clean smooth doors.</b>   |
| <b>Exterior &amp; Handles (Stainless Steel Models Only)</b> | <ul style="list-style-type: none"> <li>• Soap and water</li> <li>• Stainless Steel Cleaners</li> </ul>                    | <p><b>Never use CHLORIDE or cleaners with bleach to clean stainless steel.</b></p> <p>Clean stainless steel front and handles with non-abrasive soapy water and a dishcloth. Rinse with clean water and a soft cloth. Use a non-abrasive stainless steel cleaner. These cleaners can be purchased at most home improvement or major department stores. Always follow manufacturer's instructions. Do not use household cleaners containing ammonia or bleach.</p> <p><b>NOTE: Always clean, wipe and dry with the grain to prevent scratching.</b> Wash the rest of the cabinet with warm water and mild liquid detergent. Rinse well, and wipe dry with a clean soft cloth. Stainless steel cleaning supplies can be purchased from <a href="http://www.frigidaire.com">www.frigidaire.com</a></p> |

# BEFORE YOU CALL

**1-800-944-9044** (United States)  
**1-800-265-8352** (Canada)

Visit our web site at  
[www.frigidaire.com](http://www.frigidaire.com)

| PROBLEM                                     | CAUSE   | CORRECTION  |
|---|---|---|
| <b>APPLIANCE OPERATION</b>                  |   |   |
| Appliance does not run.                     | <ul style="list-style-type: none"> <li>Appliance is plugged into a circuit that has a ground fault interrupt.</li> <li>Temperature Control is in the OFF position.</li> <li>Appliance may not be plugged in or plug is loose.</li> <li>House fuse blown or tripped circuit breaker.</li> <li>Power outage.</li> </ul>   | <ul style="list-style-type: none"> <li>Use another circuit. If you are unsure about the outlet, have it checked by a certified technician.</li> <li>See <b>ELECTRONIC CONTROL</b> section.</li> <li>Ensure plug is tightly pushed into outlet.</li> <li>Check/replace fuse with a 15-amp time-delay fuse. Reset circuit breaker.</li> <li>Check house lights. Call local electric company.</li> </ul>   |
| Appliance runs too much or too long.        | <ul style="list-style-type: none"> <li>Room or outside weather is hot.</li> <li>Appliance has recently been disconnected for a period of time.</li> <li>Large amounts of warm or hot food have been stored recently.</li> <li>Door is opened too frequently or too long.</li> <li>Door may be slightly open.</li> <li>Temperature control is set too low.</li> <li>Gaskets are dirty, worn, cracked, or poorly fitted.</li> </ul> | <ul style="list-style-type: none"> <li>It's normal for the appliance to work longer under these conditions.</li> <li>It takes 24 hours for the appliance to cool down completely.</li> <li>Warm food will cause appliance to run more until the desired temperature is reached.</li> <li>Warm air entering the appliance causes it to run more. Open door less often.</li> <li>See <b>"DOOR PROBLEMS"</b>.</li> <li>Turn control knob to a warmer setting. Allow several hours for the temperature to stabilize.</li> <li>Clean or change gasket. Leaks in door seal will cause appliance to run longer in order to maintain desired temperatures.</li> </ul> |
| <b>APPLIANCE TEMPERATURES</b>               |   |   |
| Interior appliance temperature is too cold. | <ul style="list-style-type: none"> <li>Temperature control is set too low.</li> </ul>   | <ul style="list-style-type: none"> <li>Set control to a warmer setting. Allow several hours for temperature to stabilize.</li> </ul>  |
| Temperature inside appliance is too warm.   | <ul style="list-style-type: none"> <li>Temperature control is set too warm.</li> <li>Door is opened too frequently or too long.</li> <li>Door may not be seating properly.</li> <li>Large amount of warm or hot food has been stored recently.</li> <li>Appliance has recently been disconnected for a period of time.</li> </ul>   | <ul style="list-style-type: none"> <li>Turn control to a colder setting. Allow several hours for temperature to stabilize.</li> <li>Warm air enters the appliance every time the door is opened. Open door less often.</li> <li>See <b>"DOOR PROBLEMS"</b>.</li> <li>Wait until the appliance has had a chance to reach its selected temperature.</li> <li>Appliance requires 24 hours to cool down completely.</li> </ul>  |
| "LO" is displayed on control.               | <ul style="list-style-type: none"> <li>Control has been locked.</li> </ul>  | <ul style="list-style-type: none"> <li>Press the CONTROL LOCK key for three seconds to unlock.</li> </ul>   |
| "E7", "E8", "E9" is displayed on control.   | <ul style="list-style-type: none"> <li>The control has registered an error code.</li> </ul>   | <ul style="list-style-type: none"> <li>For toll-free telephone support in the U.S. and Canada: 1-800-374-4432</li> </ul>  |
| "Sb" is displayed on control.               | <ul style="list-style-type: none"> <li>The control is in Sabbath Mode.</li> </ul>   | <ul style="list-style-type: none"> <li>Pressing the CONTROL LOCK and TEMP MODE keys to exit Sabbath Mode.</li> </ul>  |

# BEFORE YOU CALL

| PROBLEM  | CAUSE  | CORRECTION  |
|--|--|---|
| <b>SOUND AND NOISE</b>   |  |   |
| Louder sound levels whenever appliance is on.                                      | <ul style="list-style-type: none"> <li>Appliance operates at higher pressures during the start of the ON cycle.</li> </ul>   | <ul style="list-style-type: none"> <li>This is normal. Sound will level off or disappear as appliance continues to run.</li> </ul>  |
| Popping or cracking sound when compressor comes on.<br>Bubbling or gurgling sound. | <ul style="list-style-type: none"> <li>Metal parts undergo expansion and contraction, as in hot water pipes.</li> <li>Refrigerant (used to cool refrigerator) is circulating throughout the system.</li> </ul> | <ul style="list-style-type: none"> <li>This is normal. Sound will level off or disappear as appliance continues to run.</li> <li>This is normal.</li> </ul>   |
| Vibrating or rattling noise.   | <ul style="list-style-type: none"> <li>Appliance is not level. It rocks on the floor when it is moved slightly.</li> <li>Floor is uneven or weak.</li> <li>Appliance is touching the wall.</li> </ul>          | <ul style="list-style-type: none"> <li>Level the appliance. Refer to "Leveling" section.</li> <li>Ensure floor can adequately support the appliance. Level the appliance by putting wood or metal shims under part of the appliance.</li> <li>Re-level appliance or move appliance slightly. Refer to "Leveling" in the <b>INSTALLATION</b> section.</li> </ul> |
| <b>WATER / MOISTURE / FROST INSIDE APPLIANCE</b>                                   |  |   |
| Moisture forms on inside appliance walls.  | <ul style="list-style-type: none"> <li>Weather is hot and humid, which increases internal rate of frost buildup.</li> <li>Door is slightly open.</li> <li>Door is kept open too long.</li> </ul>               | <ul style="list-style-type: none"> <li>This is normal.</li> <li>See "<b>DOOR PROBLEMS</b>".</li> <li>Open the door less often.</li> </ul>   |
| <b>ODOR IN APPLIANCE</b>   |  |   |
| Odors in appliance.  | <ul style="list-style-type: none"> <li>Interior needs to be cleaned.</li> <li>Foods with strong odors are in the appliance.</li> </ul>   | <ul style="list-style-type: none"> <li>Clean interior with sponge, warm water, and baking soda. Replace air filter.</li> <li>Cover the food tightly.</li> </ul>   |
| <b>DOOR PROBLEMS</b>   |  |   |
| Door will not close.   | <ul style="list-style-type: none"> <li>Appliance is not level. It rocks on the floor when it is moved slightly.</li> <li>Floor is uneven or weak.</li> </ul>   | <ul style="list-style-type: none"> <li>This condition can force the cabinet out of square and misalign the door. Refer to "Leveling" section.</li> <li>Ensure floor can adequately support appliance. Level the appliance by putting wood or metal shims under part of the appliance.</li> </ul>  |
| <b>LIGHTING PROBLEMS</b>   |  |   |
| LED light is not on.   | <ul style="list-style-type: none"> <li>The LED light is burned out.</li> <li>No electric current is reaching the appliance.</li> <li>Control is in Sabbath mode (Sb is displayed on control).</li> </ul>       | <ul style="list-style-type: none"> <li>Follow directions under <b>INTERIOR LIGHTING</b> section.</li> <li>See "<b>Appliance does not run</b>".</li> <li>Depress TEMP MODE key and CONTROL LOCK key for 3 seconds.</li> </ul>  |
| The SHOWCASE mode lighting is not on.  | <ul style="list-style-type: none"> <li>The SHOWCASE mode light switch has been pressed twice and released (turns SHOWCASE mode off).</li> </ul>  | <ul style="list-style-type: none"> <li>Open the door, and press and release the smaller gray switch located at the bottom of the cabinet front. After closing the door, the interior lights will remain on.</li> </ul>  |

# MAJOR APPLIANCE WARRANTY

Your appliance is covered by a one year limited warranty. For one year from your original date of purchase, Electrolux will pay all costs for repairing or replacing any parts of this appliance that prove to be defective in materials or workmanship when such appliance is installed, used and maintained in accordance with the provided instructions.

## Exclusions

### This warranty does not cover the following:

1. Products with original serial numbers that have been removed, altered or cannot be readily determined.
2. Product that has been transferred from its original owner to another party or removed outside the USA or Canada.
3. Rust on the interior or exterior of the unit.
4. Products purchased "as-is" are not covered by this warranty.
5. Food loss due to any refrigerator or freezer failures.
6. Products used in a commercial setting.
7. Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions.
8. Service calls to correct the installation of your appliance or to instruct you how to use your appliance.
9. Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc., which are not a part of the appliance when it is shipped from the factory.
10. Service calls to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts.
11. Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska.
12. Damages to the finish of appliance or home incurred during installation, including but not limited to floors, cabinets, walls, etc.
13. Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God.

## DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES

CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS PROVIDED HEREIN. CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

## If You Need Service

Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below.

This warranty only applies in the USA and Canada. In the USA, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc. In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty. Obligations for service and parts under this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice.

**USA**  
**1.800.944.9044**  
Frigidaire  
10200 David Taylor Drive  
Charlotte, NC 28262



**Canada**  
**1.800.265.8352**  
Electrolux Canada Corp.  
5855 Terry Fox Way  
Mississauga, Ontario, Canada  
L5V 3E4