ASSEMBLY INSTRUCTIONS

ATTENTION: THIS PRODUCT IS NOT FOR COMMERCIAL USE INTENDED FOR RESIDENTIAL USE ONLY.

TGS23FG

PARTS LIST

PART NO.	MATERIAL CODE	PART	Q'TY
1	TGS23FG-CS01	TABLE TOP	1
2	TGS23FG-CS02	LEG	4
3	62TGS23FGY101	CENTER CONNECTOR	1
4	17C17A0403001Y4	SCREW ST4.2*12	4

PART NO.	MATERIAL CODE	PART	Q'TY
5	17C01A0706002Y4	BOLT M6*16	8
6	17FA05040301-Y4	WASHER d6.5*D13*1.0	8
7	18000337002	BOLT CAP M6	8
8	17KAA0201Y4	HEX.KEY WRENCH 6MM	1


You will need the following tools:

- Phillips Screwdriver (Not Included)



Step 1:

Place the table top (#1) onto a non-abrasive surface, such as a carpet, with its underside facing up. Insert the legs (#2) into the plastic holders on the table top (#1) rim. Fasten them together by using screws (#4). See Figure 1.



⚠ Use the correct bolts as indicated. Do not tighten any of the bolts until the table is completely assembled.

Do not sit or stand on this table.

Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.

Keep children away during assembly. This item contains small parts that can be swallowed by children. Children should always be under direct adult supervision while using this product.

Retain these assembly instructions for future reference.


Quote the following FQC NO. when contacting the service center.

SERVICE CENTER TOLL FREE NO.

TEL: 1-877-539-7436 FAX: 1-877-539-7439



DON'T RETURN TO STORE!





Fasten the center connector (#3) to the middle of the legs (#2) by using bolts (#5) and washers (#6). Make sure that all of the bolts have been tightened completely, and then cover them with bolt caps (#7). See Figure 2.



Step 3:

Turn the table to its upright position. See Figure 3.

Cleaning and Maintenance

- Wash frame parts with mild soap and water, rinse thoroughly, and dry frame completely. Do not use bleach, acid, or other solvents on the frame parts.
- Wash glass with mild soap and water, rinse thoroughly, and dry glass completely.
- Please inspect and tighten all bolts and fasteners on a regular basis to ensure proper performance and safety of your table.
- When moving the table, do not drag.
- We recommend the use of furniture covers when not in use.
- In order to prolong the life and beauty of your table, we recommend it be stored in a dry and protected area during off season periods.

Warranty

- This product is covered by Courtyard Creations Inc. One—year limited warranty.
- Proof of purchase (dated register receipt) is required for warranty claims.
- It remains the customer's responsibility for freight and packing charges to and from over service center.

STOP!

Missing A Part? No Need To Go Back To

The Store

The store where you made your purchase does not stock parts for this item.

If you need parts,
whether they are missing or damaged,
Call Toll Free:
TEL: 1-877-539-7436
FAX: 1-877-539-7439
Call us between 9:00 AM and 4:30 PM
Eastern Time Monday through Friday
For further assistance,
please visit us at

service.cci@polywares.com

READ THESE INSTRUCTIONS COMPLETELY BEFORE STARTING ASSEMBLY

- ★ SEPARATE AND IDENTIFY ALL PARTS, MAKING SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
- ★ IF YOU DO NOT LOCATE ALL OF THE PARTS LISTED, INSPECT THE PACKING MATERIAL FOR SMALL PARTS THAT MAY HAVE BECOME SEPARATED DURING SHIPMENT.
- ★ IF YOU EXPERIENCE ANY DIFFICULTY DURING ASSEMBLY OR IF ANY PARTS ARE MISSING OR DAMAGED, CALL THE HELP LINE AT 1-877-539-7436 BEFORE RETURNING THIS ITEM TO THE STORE.
- ★ PROVIDE THE FOLLOWING INFORMATION WHEN CALLING:

 1-MODEL NUMBER OF THE PRODUCT.

 2-PART NUMBER AND MATERIAL CODE OF THE PART FROM THE PARTS

 LIST.
- ★MOST PROBLEMS CAN BE RESOLVED WITHOUT RETURNING THIS PRODUCT TO THE RETAILER.



DON'T RETURN TO STORE!

PAGE 2 OF 2