

Xerox Green
World Alliance
Product Take-Back List



Xerox Green World Alliance

Product Take-Back List



Xerox Green World Alliance

Product Take-Back List

Over the last twenty years our supplies recycling programs have kept millions of pounds of waste out of landfills. As part of our continued commitment to environmentally responsible business practices, Xerox has made significant improvements to our returns and recycling programs.

Overview

Significant work has been conducted to look at the impact to the environment and the value of bringing each used item back for processing individually. The items listed here and on the website today are those items for which Xerox will pay the individual return shipping and processing costs.

Xerox encourages you to recycle items not on the “take back” list locally. Some products, identified as number 2 plastics, may be recycled in your local mixed plastic stream. If you are at a business location with an industrial recycling program, then a wider range of items may be recycled through that program.

Supplies used in our products are also designed for safe local disposal. Please contact your Municipal Waste Service or Industrial Recycling Provider for more information as programs vary. Alternatively, items not on the take back list can also be returned to our authorized recycling partner and Xerox will pay the processing fees associated with the asset recovery while the customer pays the shipping charges to return the items.

How do I locate my part number?

The part number (or SKU number) of a customer replaceable supply item is an alpha numeric code typically containing an “R.”

To locate this number please review the panels on the carton as the number usually occurs on two or more panels. In most cases, the number will be located on the bottom right side of the panel below the Xerox logo

How to Return Items

Items can be returned to the Xerox Authorized Recycling partner at the following address:

Xerox Recycling
2051 Meridian Place Building 3
Hebron, KY. 41048

As an alternative to returning items individually, Xerox encourages use of the pre-paid Eco Box or Bulk Returns program as an economical way to return all of your used Genuine Xerox® Supply items found on the take-back list for recycling.

For more information on the Eco Box or Bulk Returns Program, please visit xerox.com/gwa



Xerox® Branded Replacement Cartridges

Part number	Description	Equipment using this part
All	Toner cartridge	HP replacement cartridges by Xerox
All	Toner cartridge	Brother replacement cartridges by Xerox
All	Toner cartridge	Lexmark replacement cartridges by Xerox

Xerox® Cartridges

Part number	Description	Xerox® equipment using this part
001R00600	IBT Cleaner Assy	Xerox® WorkCentre® 7425/7428/7435
001R00613	IBT Cleaner Assy	WorkCentre 7525/7530/7535/7545/7556
005K09880	Fuser Web Cartridge	Xerox® Color 800/1000 Press
005K12641	Fuser Web Cartridge	Xerox Nuvera® 100/120, Xerox Nuvera® 200/288/314 EA, Xerox Nuvera® 100/120/144/157 EA
005K12642	Fuser Web Cartridge	Xerox Nuvera® 100/120, Xerox Nuvera® 200/288/314 EA, Xerox Nuvera® 100/120/144/157 EA
005K12790	Fuser Web Cartridge	Xerox Nuvera® 100/120/144 MX, Xerox Nuvera® 200/288 MX
005K12791	Fuser Web Cartridge	Xerox Nuvera® 100/120/144 MX, Xerox Nuvera® 200/288 MX
006R00244	Black Toner	Xerox® 5018, 5021, 5028, 5034, 5328, 5334, 5624®, 5626®, 5820, 5826, 5830
006R01274	Toner Cartridge	WorkCentre 4150
006R01275	Toner Cartridge	WorkCentre 4150
006R01278	Toner Cartridge	Xerox® FaxCentre® 2218, WorkCentre 4118
008R12933	Fuser	Xerox® CopyCentre® C2128, C2636, C3545, WorkCentre Pro C2128/C2636/C3545
008R12988	Fuser	Xerox® DocuColor® 240/242/250/252, WorkCentre 7655/7665/7675
008R13026	2nd BTR Unit	WorkCentre 7232/7242 Multifunction Printer
008R13036	Waste Toner Bottle	Xerox® 4112® CP Enterprise Printing System
008R13039	Fuser	DocuColor 260 Copier/Printer
008R13042	Fuser Web	Xerox® 4110/4112, 4127®, 4590/4595®
008R13044	Fuser	WorkCentre 7232, 7242
008R13052	Fuser Web	DocuColor 5000/5000AP, 6060, 7000/7000AP, 8000/8000AP
008R13055	Fuser	WorkCentre 7228, 7335, 7345, 7346
008R13062	Fuser	WorkCentre 7425, 7428, 7435
008R13065	Fuser	DocuColor 7000
008R13085	Fuser Web	Xerox® 4110/4112, 4127, 4590/4595EPS, 4595
008R13087	Fuser	WorkCentre 7120
008R13089	Waste Toner Bottle	WorkCentre 7120/7125
008R13091	Fuser Web Cartridge	Xerox® XC800/XC1000
008R13102	Fuser	Xerox® Color 550, Color 560
008R13103	Fuser Web Cartridge	Xerox® XC800/XC1000
008R13104	Label	Xerox® Eco Box Return Label
008R13110	Black Printhead Unit	Xerox® CiPress® 325/500 Production Inkjet System
008R13111	Cyan Printhead Unit	Xerox® CiPress® 325/500 Production Inkjet System
008R13112	Magenta Printhead Unit	Xerox® CiPress® 325/500 Production Inkjet System
008R13113	Yellow Printhead Unit	Xerox® CiPress® 325/500 Production Inkjet System
008R13139	Fuser Web Cartridge	Xerox Nuvera® 100/120, Xerox Nuvera® 200/288/314 EA, Xerox Nuvera® 100/120/144/157 EA

Product Take-Back List (cont.)

Part number	Description	Xerox® equipment using this part
008R13140	Fuser Web Cartridge	Xerox Nuvera® 100/120/144 MX, Xerox Nuvera® 200/288 MX
008R13141	Fuser Web Cartridge	Xerox Nuvera® 100/120/144 MX, Xerox Nuvera® 200/288 MX
008R13146	Cleaning Web	Xerox® Color C75/J75 Press
013R00009	Copy Cartridge	Xerox® 5018, 5028, 5034
013R00067	Copy Cartridge	Xerox® 5334
013R00074	Copy Cartridge	Xerox® Color 1875, 675, 5016, 5126
013R00505	Copy Cartridge	Xerox® 5034, 5328, 5321
013R00557	Copy Cartridge	DocuColor 12 Digital Color Copier/Printer, Document Centre Color Series 50
013R00558	Copy Cartridge	DocuColor 12 Digital Color Copier/Printer, Document Centre Color Series 50
013R00559	Copy Cartridge	DocuColor 12 Digital Color Copier/Printer, Document Centre Color Series 50
013R00560	Copy Cartridge	DocuColor 12 Digital Color Copier/Printer, Document Centre Color Series 50
013R00579	Drum Cartridge	CopyCentre C32/C40, DocuColor 3535, WorkCentre M24, WorkCentre Pro C32/C40
013R00581	Copy Cartridge	Xerox® DocuColor 2045, 2060, 5252, 5000
013R00583	Copy Cartridge	DocuColor 8002, 2045, 2060, 5252, 5000, 7000, 7002, 8000
013R00588	Drum Cartridge	CopyCentre C2128, C2636, C3545, WorkCentre Pro C2128/C2636/C3545, C2128, C2636, C3545
013R00590	Copy Cartridge	DocuColor 6060
013R00591	Drum Cartridge	WorkCentre 5325/5330/5335
013R00602	Drum Cartridge	DocuColor 240/250, DocuColor 242/252 Copier/Printer, DocuColor 260 Copier/Printer, WorkCentre 7655/7665/7675 Copier/Printer
013R00603	Drum Cartridge	DocuColor 240/250, DocuColor 242/252 Copier/Printer, DocuColor 260 Copier/Printer, WorkCentre 7655/7665/7675 Copier/Printer
013R00610	Drum Cartridge	Xerox® 4590, 4110
013R00613	Drum Cartridge	DocuColor 5000
013R00616	Drum Cartridge	DocuColor 5000
013R00617	Drum Cartridge	DocuColor 5000, DocuColor 5000AP
013R00620	Drum Cartridge	WorkCentre Pro 65, 75, CopyCentre CC65, CC75
013R00623	Drum Cartridge	WorkCentre 4150
013R00624	Drum Cartridge	WorkCentre 7245/7328/7335/7346
013R00629	Corotron Assembly	DocuColor 6060/7000/7002/8000/8002/8080/7000AP/8000AP
013R00631	Drum Cartridge	DocuColor 260 Copier/Printer
013R00632	Drum Cartridge	DocuColor 260 Copier/Printer
013R00635	Drum Cartridge	Xerox® 4110, 4590
013R00639	Drum Cartridge	Xerox® 4110, 4590, 4595
013R00640	Drum Cartridge	Xerox® 4110, 4112, 4127, 4590, 4595
013R00642	Drum Cartridge	Xerox® 700
013R00643	Drum Cartridge	Xerox® 700
013R00646	Drum Cartridge	Xerox® 4110, 4112, 4127, 4590, 4595
013R00647	Drum Cartridge	WorkCentre 7425, 7428, 7435
013R00648	Drum Cartridge	DocuColor 5000, DocuColor 5000AP
013R00649	Drum Cartridge	DocuColor 5000, DocuColor 5000AP
013R00652	Copy Cartridge	Xerox® 4110, 4590, 4595, 4112, 4127
013R00653	Copy Cartridge	Xerox® 4110, 4590, 4595, 4112, 4127

Part number	Description	Xerox® equipment using this part
013R00655	Copy Cartridge	Xerox® 700 Digital Color Press, Xerox® F116, Xerox® F116L
013R00656	Copy Cartridge	Xerox® 701 Digital Color Press, Xerox® F116, Xerox® F116L
013R00661	Copy Cartridge	DocuColor 8000, 800AP, 8002
013R00662	Drum Cartridge	WorkCentre 7525/7530/7535/7545/7556
013R00663	Copy Cartridge	Xerox® Color 550, 560
013R00664	Copy Cartridge	Xerox® Color 550, 560
013R00666	Copy Cartridge	Xerox® D95/D110/D125
013R00667	Copy Cartridge	DocuColor 8000/8000AP/7002/8002/8080
013R00668	Drum Cartridge	D-Series D95/110/125
013R00671	Copy Cartridge	Xerox® Color C75/J75 Press
013R00672	Copy Cartridge	Xerox® Color C75/J75 Press
013R90125	Copy Cartridge	Xerox® Document Centre® 332/340, Document Centre 425/430/432/440 DC/ST
013R90130	Copy Cartridge	Xerox® Document Centre® 220/230, Document Centre 420/426
042K02112	IBT Cleaner Assy	DocuColor 6060/7000/7002/8000/8002/7000AP/8000AP
042K03110	IBT Cleaner Assy	DocuColor 6060/7000/7002/8000/8002/8080/7000AP/8000AP
042K03450	IBT Cleaner Assy	Xerox® Color 800/1000 Press
042K92757	CLEANER IBT	DocuColor 240/250, DocuColor 242/252 Copier/Printer, DocuColor 260 Copier/Printer, WorkCentre 7655/7665/7675 Copier/Printer
042K93161	CLEANER IBT	Xerox® DocuColor 5000
042K93162	CLEANER IBT	Xerox® DocuColor 5000
042K93163	CLEANER IBT	Xerox® DocuColor 5000
042K93480	CLEANER ASSY-I	Xerox® 700
042K93690	IBT Cleaner Assy	Xerox® Color 800/1000 Press
042K93691	IBT Cleaner Assy	Xerox® Color 800/1000 Press
042K94151	CLEANER ASSY I	Xerox® 700
042K94250	IBT Cleaner Assy	Xerox® Color 800/1000 Press
059K34717	Transfer Detack	CopyCentre 55, WorkCentre Pro 35/45/55, DocuCentre® 535/545/555, WorkCentre 5030/5050, WorkCentre 5632/5638/5645/5655/5665/5675/5687
059K35364	Transfer Detack	CopyCentre 55, WorkCentre Pro 35/45/55, DocuCentre 535/545/555, WorkCentre 5030/5050, WorkCentre 5632/5638/5645/5655/5665/5675/5688
059K58210	Transfer Detack	CopyCentre 55, WorkCentre Pro 35/45/55, DocuCentre 535/545/555, WorkCentre 5030/5050, WorkCentre 5632/5638/5645/5655/5665/5675/5689
059K58220	Transfer Detack	CopyCentre 55, WorkCentre Pro 35/45/55, DocuCentre 535/545/555, WorkCentre 5030/5050, WorkCentre 5632/5638/5645/5655/5665/5675/5690
059K60570	Fuser	Xerox® Color 800/1000 Press
059K60580	Fuser	Xerox® Color 800/1000 Press
059K86850	Fuser	Xerox® Color 800/1000 Press
064K02120	2nd Transfer Assy	DocuColor 7000/7002/8000/8002/8080/7000AP/8000AP
064K92030	2nd Transfer Assy	DocuColor 7000/7002/8000/8002/7000AP/8000AP
064K92040	2nd Transfer Assy	DocuColor 7000/7002/8000/8002/7000AP/8000AP
064K93251	Belt Module Assembly	Xerox® Color 800/1000 Press
064K93252	Fuser	Xerox® Color 800/1000 Press

Product Take-Back List (cont.)

Part number	Description	Xerox® equipment using this part
084K09014	Fuser	CopyCentre 32/45/55/65/75/87, DocuColor 32/28/45/55/65/75/87
084K09015	Fuser	CopyCentre 32/45/55/65/75/87, DocuColor 32/28/45/55/65/75/87
084K29920	Fuser	CopyCentre 32/45/55/65/75/87, DocuColor 32/28/45/55/65/75/87
090H3566	Copy Cartridge	Xerox® DocuPrint® N3225, N4025, N32, N33, N40, N24
097K32970	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
101R00435	Drum Cartridge	WorkCentre 5222/5225/5230
106R00584	Toner Cartridge	WorkCentre M15, WorkCentre M15i, Fax Centre F12
106R00586	Toner Cartridge	WorkCentre M15, WorkCentre M15i, WorkCentre Pro 412
106R01047	Toner Cartridge	CopyCentre C20, WorkCentre M20, WorkCentre M20i
106R01048	Toner Cartridge	WorkCentre M20/M20i, CopyCentre C20
106R01369	Print Cartridge	Xerox® Phaser® 3600
106R01370	Print Cartridge	Phaser 3600
106R01371	Print Cartridge	Phaser 3600
106R01372	Print Cartridge	Phaser 3600
106R01373	Print Cartridge	Phaser 3250
106R01374	Print Cartridge	Phaser 3250
106R01408	Toner Cartridge	WorkCentre 4250
106R01409	Toner Cartridge	WorkCentre 4251
106R01485	Copy Cartridge	WorkCentre 3210/3220
106R01486	Copy Cartridge	WorkCentre 3210/3220
106R01527	Print Cartridge	WorkCentre 3550
106R01528	Print Cartridge	WorkCentre 3550
106R01530	Print Cartridge	WorkCentre 3550
106R01532	Toner Cartridge	Phaser 4600/4620
106R01533	Toner Cartridge	Phaser 4600/4620
106R01535	Toner Cartridge	Phaser 4600/4620
106R01582	Drum Cartridge	WorkCentre 7525/7530/7535/7545/7556
106R02626	Toner Cartridge	Phaser 3635
108R00581	Drum Cartridge	WorkCentre 7328/7335/7345/7346
108R00713	Drum Cartridge	WorkCentre 7328/7335/7345/7346
108R00792	Toner Cartridge	Phaser 3635 MFP
108R00793	Toner Cartridge	Phaser 3635 MFP
108R00795	Toner Cartridge	Phaser 3635 MFP
108R00841	Cleaning Unit	Xerox® ColorQube® 9201, 9202, 9203
108R00861	Drum Cartridge	WorkCentre 7425/7428/7435
108R00989	Cleaning Unit	ColorQube 9301/9302/9303
109R00327	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00328	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00329	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00330	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX

Part number	Description	Xerox® equipment using this part
109R00340	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00344	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00347	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00491	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00492	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00494	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00496	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00511	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00512	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00514	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00516	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00636	Fuser	CopyCentre C35/C45/C55, DocuCentre 555/545/535, WorkCentre M35/M45/M55, WorkCentre 5030/5050
109R00723	Fuser	WorkCentre Pro 265, WorkCentre 275, CopyCentre 232/238/245/255
109R00728	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00730	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
109R00752	Fuser	WorkCentre Bookmark 40/55, WorkCentre 232/238/245/255, WorkCentre 5632/5638/5645/5655, WorkCentre Pro 232/238/245/255, CopyCentre 265/275, WorkCentre 5135/5150 MP
109R00773	Fuser	WorkCentre 5665, WorkCentre 5675, WorkCentre 5687
113R00093	Copy Cartridge	Xerox® 5018, 5028, 5034, 5021, 5328
113R00120	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00131	Xerographic Module	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
113R00132	Xerographic Module	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
113R00161	Copy Cartridge	Xerox® 5018, 5028, 5034, 5021, 5328
113R00162	Copy Cartridge	Xerox® 5016/5018/5021/5028/5034/5126/5328/5818/5820/XC1875/XC2675
113R00173	Copy Cartridge	DocuPrint N3225, N4025, N32, N33, N40, N24
113R00179	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00184	Copy Cartridge	DocuPrint N3225, N4025, N32, N33, N40, N24
113R00195	Copy Cartridge	DocuPrint N4525
113R00270	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00271	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00272	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00273	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00274	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00275	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00276	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00278	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00280	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00281	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00282	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00307	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00308	Copy Cartridge	Xerox® 5018/5028/5034/5021/5228

Product Take-Back List (cont.)

Part number	Description	Xerox® equipment using this part
113R00313	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00315	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00316	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00317	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00318	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00319	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00321	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00324	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00326	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
113R00444	Copy Cartridge	Xerox® 5018/5028/5034/5021/5328
113R00482	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00483	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00484	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00485	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00486	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
113R00607	Copy Cartridge	WorkCentre 265, WorkCentre 275
113R00608	Copy Cartridge	WorkCentre 232/238/245/255, WorkCentre Pro 232/238/245/255, CopyCentre C35/C45/C55, CopyCentre 232/238/245/255, Document Centre 555/545/535, WorkCentre M35/M45/M55, WorkCentre 5030/5050, WorkCentre 5135/5150MFP, WorkCentre Pro 35/45/55
113R00610	Copy Cartridge	WorkCentre 232/238/245/255, WorkCentre Pro 232/238/245/255, CopyCentre C35/C45/C55, CopyCentre 232/238/245/255, Document Centre 555/545/535, WorkCentre M35/M45/M55, WorkCentre 5030/5050, WorkCentre 5135/5150MFP, WorkCentre Pro 35/45/55
113R00620	Copy Cartridge	WorkCentre Pro 65, WorkCentre Pro 75, CopyCentre CC65, CopyCentre CC75
113R00621	Xerographic Module	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
113R00622	Xerographic Module	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
113R00623	Xerographic Module	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
113R00624	Xerographic Module	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
113R00663	Drum Cartridge	WorkCentre M15, WorkCentre M15i, WorkCentre Pro 412
113R00670	Drum Cartridge	Phaser 5500/5550
113R00671	Drum Cartridge	CopyCentre C20, WorkCentre M20, WorkCentre M20i, Fax Centre 2218
113R00672	Xerographic Module	WorkCentre Pro 245/255, WorkCentre Pro 265/275, WorkCentre Pro 232/238, CopyCentre 232/238, CopyCentre 245/255, CopyCentre 265/275, WorkCentre 5665/5675/5687, WorkCentre 5645/5655, WorkCentre 265/275, WorkCentre 245/255, WorkCentre 232/238
113R00673	Xerographic Module	WorkCentre Pro 245/255, WorkCentre Pro 265/275, WorkCentre Pro 232/238, CopyCentre 232/238, CopyCentre 245/255, CopyCentre 265/275, WorkCentre 5665/5675/5687, WorkCentre 5645/5655, WorkCentre 265/275, WorkCentre 245/255, WorkCentre 232/238, WorkCentre M165/M175
113R00674	Xerographic Module	WorkCentre Pro 165/175, WorkCentre Pro 245/265/275, WorkCentre M165/M175, WorkCentre 245, CopyCentre 245, CopyCentre C165/C175
113R00755	Drum Cartridge	WorkCentre 4250/4260
113R00762	Drum Cartridge	Phaser 4600/4620
115R00061	Fuser	Phaser 7500
115R00073	Fuser	Phaser 7800

Part number	Description	Xerox® equipment using this part
125K04473	AC DICOR-PRECL	Xerox® iGen3™
125K04491	AC DICOR MOD	iGen3
125K04493	AC DICOR MOD	iGen3
125K05030	Charge Corotron	Xerox® Color 800/1000 Press
125K93012	Corotron Assembly	DocuColor 45
125K93820	Charge Corotron	Xerox® Color 800/1000 Press
126K16480	Fuser Unit 120	WorkCentre Pro 123/128/133
126K16481	Fuser Unit 120	WorkCentre Pro 123/128/133
126K24980	Fuser	WorkCentre 5222/5225/5230/5225A/5230A
126K24981	Fuser	WorkCentre 5222/5225/5230/5225A/5230A
126K24982	Fuser	WorkCentre 5222/5225/5230/5225A/5230A
126K24983	Fuser	WorkCentre 5222/5225/5230/5225A/5230A
126K29391	Fuser	WorkCentre 5325/5330/5335
126K29392	Fuser	WorkCentre 5325/5330/5335
126K29393	Fuser	WorkCentre 5325/5330/5335
126K38640	Fuser	WorkCentre 5222/5225/5230/5225A/5230A
604K17970	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
604K20340	Fuser 120V Kit	WorkCentre Pro 123/128/133
604K20342	Fuser 120V Kit	WorkCentre Pro 123/128/133
604K20343	Maintenance Kit	CopyCentre C123, CopyCentre C128, WorkCentre M123, WorkCentre M128, WorkCentre Pro 123, WorkCentre Pro 128, WorkCentre Pro 133
604K30251	Corotron Assembly	DocuColor 5252
604K62200	Fuser	WorkCentre M35/M45/M55, WorkCentre Pro 35/45/55
604K62210	Fuser	WorkCentre 45/56
604K62320	Fuser	Xerox® Color 800/1000 Press
604K62321	Belt Module	Xerox® Color 800/1000 Press
622S00013	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
622S00014	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
622S00015	Fuser	Document Centre 240/255/265/460/470/480/490, CopyCentre CC65/75/90, WorkCentre Pro 65/75/90, DocuPrint 75MX
622S00044	Fuser	DocuColor 240/250, DocuColor 242/252 Copier/Printer, DocuColor 260 Copier/Printer
622S00191	Fuser 120V Kit	WorkCentre Pro 123/128/133
622S00343	Fuser Web Cartridge	Xerox Nuvera® 100/120, Xerox Nuvera® 200/288/314 EA, Xerox Nuvera® 100/120/144/157 EA
622S00344	Fuser Web Cartridge	Xerox Nuvera® 100/120/144 MX, Xerox Nuvera® 200/288 MX
622S00807	Fuser	DocuColor 260 Copier/Printer
622S00915	Fuser	Xerox® 700 Digital Color Press, Xerox® 770 Digital
673K42381	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
673K42391	Copy Cartridge	Document Centre 220/230, Document Centre 420/426
673K55310	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
673K60730	Copy Cartridge	Document Centre 332/340, Document Centre 425/430/432/440 DC/ST
673K60740	Copy Cartridge	Document Centre 220/230, Document Centre 420/426

Product Take-Back List (cont.)

Part number	Description	Xerox® equipment using this part
675K87090	Copy Cartridge	Xerox® Color 800/1000 Press
675K87091	Drum Cartridge	Xerox® Color 800/1000 Press
848K77540	Drum Cartridge	Xerox® Color 800/1000 Press
848K77541	Drum Cartridge	Xerox® Color 800/1000 Press
All	Toner Cartridge	Xerox® Brother replacement cartridges
All	Toner Cartridge	Xerox® HP replacement cartridges

HP Replacement Cartridges

Part number	Description	HP equipment using this part
CC530A	Black Toner	CP2025/CM2320
CC531A	Cyan toner	CP2025/CM2320
CC532A	Magenta toner	CP2025/CM2320
CC533A	Yellow Toner	CP2025/CM2320
CE250A	Black Toner	CP3525A
CE251A	Cyan toner	CP3525
CE252A	Yellow Toner	CP3525
CE253A	Magenta toner	CP3525
CE250X	Black Toner	CP3525X
CE260A	Black Toner	CP4525A
CE261A	Cyan toner	CP4525
CE262A	Magenta toner	CP4525
CE263A	Yellow Toner	CP4525
CE260X	Black Toner	CP4525X
Q1338AG	Toner Cartridge	HP LaserJet 4200
Q2612A	Toner Cartridge	HP LaserJet 1010
Q5942X	Toner Cartridge	HP LaserJet 4250

