


5



STEP 5: On-screen setup and activation

Follow the instructions
on your TV screen.

Activate your streaming
player by using your
computer or smartphone to
link to a Roku account.



NOTE: Roku does not charge for activation support – **beware of scams.**

Common questions

Why do I need to create a Roku account?

Before you can start streaming, channels must be downloaded and installed on your streaming player. You'll need a Roku account to access the Roku Channel Store, manage your subscriptions, view your purchase history, and add a payment method. For more info, visit go.roku.com/whyaccount

Why do I need to enter a credit card?

Saving a payment method makes it easy to rent or buy movies on demand, subscribe to popular services, and enroll in free trials. Charges will not be made without your authorization. For more information, visit go.roku.com/paymenthelp

What should I do if my streaming player is not connecting to my wireless network?

Your streaming player connects to your wireless network the same as your laptop or smartphone. If these other devices can access the internet, then your streaming player should be able to do the same. Make sure to select the same network name, and enter the same password you use with the other devices. Remember that passwords are case-sensitive and easy to enter incorrectly. For more help, visit go.roku.com/wireless

Can I take my Roku streaming player with me when I travel?

Yes. You can bring your streaming player and watch your favorite entertainment when you travel. Remember to also bring the power adaptor, remote, and any cables you use to connect your streaming player at home. Make sure your destination has a good internet connection. You may need a computer or smartphone to help connect your streaming player to a new wireless network. For more details, visit go.roku.com/travelwithroku

Need more help getting started?

go.roku.com/ultra



Video
tutorials



Wireless
help

Getting the most out of your Roku streaming player.

go.roku.com/usingroku



Add
channels



Mobile
app

Tips, what's streaming for free, and more...

blog.roku.com



Roku Blog



ROKU Ultra LT



Quick Start Guide

ROKU

© 2019 Roku, Inc. All rights reserved. ROKU and the ROKU logo are the registered trademarks of Roku, Inc. HDMI, the HDMI logo, and High-Definition Multimedia Interface are the trademarks or registered trademarks of HDMI Licensing, LLC. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.



What's included



Roku Ultra LT streaming player



Two AA Duracell® batteries



Remote




Headphones




Power adaptor

Features




Setup



STEP 1: Connect to TV


Connect your streaming player to an HDMI port on the back of your TV using a High Speed HDMI® Cable (not included).

OR




To stream 4K or HDR, choose an HDMI port that supports **HDCP 2.2**. Use a Premium High Speed HDMI® Cable (not included).

For help determining which port supports HDCP 2.2, visit go.roku.com/hdcp



STEP 2: Connect to power


Use the included power adaptor to connect your streaming player to a wall outlet.



STEP 3: Power on TV and select input

Use your TV remote to power on your TV and select the input you used to connect your streaming player.


For help on how to select the correct input, visit go.roku.com/selectinput



STEP 4: Insert batteries

On the back side of the remote, slide open the battery cover. Insert included Duracell® batteries placing the negative (-) ends in first.

Your remote should pair with your streaming player automatically. For help pairing your remote, visit go.roku.com/remotehelp



NOTE: To use private listening, simply plug headphones into your Roku® remote. Your TV will mute automatically.