


QUICK START GUIDE

1


CHARGING PROCEDURE



*Connect the battery charger to the power supply and the indicator light should turn to green.
Slide the charger base on the battery pack to make connections and the indicator light will turn red to show that the charging has started.
When charging is completed, the light will turn to green.*

2


INSTALLING THE BATTERY PACK



After recharging, insert the battery pack into the battery port. A simple push and slight pressure will be sufficient until a click is heard. Check to see if the battery is fully secured.

3

ASSEMBLY INSTRUCTIONS



*Grip the chain tensioning outer rim and turning it anti-clockwise to loosen the chain.
Hold and depress the cover tightening stick, turning it anti-clockwise to remove the chain cover.*


Read all instructions. Failure to follow all instructions listed within may result in electric shock, fire and/ or serious injury.

If you have questions or experience a problem call 1-800-840-7856

QUICK START GUIDE

4


OPERATION



Use both hands to grip saw. Always use left hand to grip front handle and right hand to grip rear handle. Use a firm grip. Thumbs and fingers must wrap around saw handles.

5


OPERATION



Hold the chain saw at the right-hand side of your body.

6

OPERATION



Do not operate the chain saw with arms fully extended, attempt to saw areas which are difficult to reach, or stand on a ladder while sawing

Read all instructions. Failure to follow all instructions listed within may result in electric shock, fire and/ or serious injury.

If you have questions or experience a problem call 1-800-840-7856