




Mainstays 4-Piece Conversation Set (Coffee Table)

BKC04610

UPC # 0 50874 06436 3



If parts are missing or you need assistance, please contact our Customer Service Center, Monday through Friday 9am - 5pm (Eastern Time) at **1-800-416-3511**.

IMPORTANT!! PLEASE READ ENTIRE INSTRUCTION SHEET BEFORE ASSEMBLY!!
TO EXPEDITE ANY FUTURE WARRANTY CLAIMS, PLEASE KEEP INSTRUCTION SHEET, WARRANTY CARD AND RECEIPT

Step 1: Carefully remove glass and set aside until Step 5. Lay glass flat--do not stand glass on edge. Remove all protective materials and set parts on a flat, non-abrasive surface. Identify parts packed in carton against the parts list. If you are missing any parts or are unsure how to proceed with assembly, call our Customer Service Center at 1-800-416-3511. **Do not attempt assembly if any parts are missing or damaged..**

Step 2: Attach the leg connector bracket to the a table leg by using the two bolts as shown in **Fig.1**. Guide the bolts through the holes in the table leg, into the pre-drilled holes in the leg connector bracket. **Hand tighten only.** Repeat for the other three legs.

Step 3: Place the table rim (without glass) upside down on a flat, non-abrasive surface. Attach the table base to the table rim by using the four bolts as shown in **Fig.2**. Guide the bolts through the holes in the table legs, into the pre-drilled holes in the table rim. **Hand tighten only.**

Step 4: After making any necessary adjustments to the alignment of the table legs and the leg connector bracket, use the hex bolt driver to tighten all bolts. **Note:** each bolt must be tightened a few revolutions at a time. In order to apply equal pressure to all bolt joints, we recommend working in a cross corner (X fashion). Repeat until all bolts are tight. **Do not over tighten.** Over tightening may strip bolts. Cover all bolts with covers.

Step 5: With the help of another person, turn the table in the upright position. Note the clear bumpers spaced evenly throughout the inside of the rim. Carefully place glass inside the rim, resting on the clear bumpers. Your table is now ready for use. If you have any questions, please call our Customer Service Center at 1-800-416-3511.

Estimated assembly time :15 minutes.

IMPORTANT NOTE: Damage to welds or frames resulting from over tightened bolts or improper assembly is not covered under our warranty. Please read all instructions carefully before assembly. If you have any questions regarding your assembly, call our Customer Service Center at 1-800-416-3511.




Fig. 1











Fig. 2

	<u>PARTS LIST</u>	<u>DESCRIPTION</u>	<u>ORDER PART #</u>	<u>QTY</u>
A		1/4" X 16 MM BOLT	HW0276	12
B		HEX BOLT DRIVER	HW0006	1

** NOTE: PARTS SHOWN BELOW ARE NOT TO SCALE*

C		TOP GLASS		1
D		TABLE TOP	ST1617	1
E		LEG CONNECTOR BRACKET	ST1618	1
F		TABLE LEG	ST1619	4
		FOOTCAP <i>FACTORY ASSEMBLY</i>	FC0069	

CARE AND MAINTENANCE

FRAMES

Cleaning - Use mild soap and warm water. Do not use abrasive materials, cleansers or bleach products. Rinse with clean water and dry thoroughly.

Maintenance - Periodically clean and dry thoroughly. Be sure to drain any water accumulated inside the frames. To thoroughly drain frames, remove foot caps and tilt the frames, if necessary, to remove all water. This is critical. Water allowed to accumulate inside the frames and then exposed to sub-freezing temperatures can cause damage to the frame tubing. Such damage is not covered under warranty. Always clean, drain and dry thoroughly before storing for the winter. For best results, always store or cover your furniture when not in use. We recommend commercially available outdoor furniture covers. Any rust spots should be lightly sanded, treated with a commercially available rust inhibitor and followed by an application of touch-up paint. Any small nicks or scratches can be covered with a light application of touch-up paint.

****** When cleaning or moving large or heavy items, always have two people work together. Never drag furniture.

GLASS

Use commercially available glass cleaners. Do not use abrasive materials, cleansers or bleach products.

SPECIAL WARNINGS!!!

GLASS WARNING!

Tempered glass is engineered to break safely into blunt pieces. However, broken glass pieces may still cause injury. PLEASE TAKE PRECAUTIONS AND DO NOT ALLOW ANYONE TO CLIMB, STAND, CRAWL OR WALK ON THE TOP OF THE GLASS TABLE. ALWAYS TAKE PRECAUTIONS TO PROTECT YOUR GLASS TABLE DURING STORMS AND HIGH WINDS.

LIMITED 1 YEAR WARRANTY

- **Frames.** Frame construction is warranted against defects in materials or workmanship for one year from purchase date. Damage to frames or welds resulting from improper assembly or exposure to water and/or sub-freezing temperatures is not covered. General frame rusting is not covered.
- **Finishes.** Paint finishes are warranted against peeling, cracking or blistering for one year from purchase date provided the unit has not been scratched or abraded. Chips and scratches resulting from normal wear and tear are not covered.
- **Fabrics.** Fabric and cushions (if applicable) are warranted against separation at the seams for one year from purchase date. Fading and/or discoloration resulting from exposure to the elements, oils, spills, fluids, chemicals, or any other cause is not covered.
- **Straps and/or wicker.** Straps and/or wicker weave (if applicable) are warranted against separation and tearing for one year from purchase date. Fading and/or discoloration resulting from exposure to the elements, oils, spills, fluids, chemicals, or any other cause is not covered.
- **Umbrellas.** Umbrellas (if applicable) are warranted against manufacturer's defects only for one year from purchase date. Umbrella bases (if applicable) are not covered under any circumstances.
- **Table tops.** Natural stone tabletops only are warranted against defects in materials and workmanship only for one year from purchase date. All table tops (including without limitation glass and faux stone) are not covered under any circumstances.

Warranty limitations: This warranty is to the original purchaser only when purchased from one of our authorized dealers and is not transferable. We will pay shipping and handling charges for replacement items within the North American continent during the first year of ownership on all valid warranty claims. After the first year, shipping and handling charges are the responsibility of the claimant/owner. We shall not be responsible for charges associated with shipments outside of the North American continent at any time.

Warranty exclusions: The following are excluded from coverage under this limited warranty: any item used for commercial, contract or any other non-residential purpose; clearance items, display models or items purchased "as is"; freight damage; items subject to misuse, abuse, or lack of proper care or maintenance; damage caused by acts of nature, acts of force majeure, vandalism, fire or improper assembly; hardware against corrosion or rusting; purchased or replacement parts; and all plastic parts. Also excluded are loss of use or time; inconveniences; money, travel, packaging or incidental, special or consequential damages of any kind. Replacement of defective items as provided herein shall constitute the sole and exclusive remedy of the purchaser for items which are not as warranted. In no event shall our responsibility exceed the purchase price of the item found to be other than as warranted. This warranty is the exclusive statement of your rights with respect to defects in the items you have purchased and supersedes any other expressed warranty or statement, written or oral, made in connection with the purchase and sale of those items. When used herein, the term "item" refers to the specific item found to be defective, and not to the entire set of which the item is a part.

Some states do not allow exclusion or limitation of incidental or consequential damages, so that limitation above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

PATIO FURNITURE & ACCESSORIES ASSEMBLY INSTRUCTIONS

IMPORTANT!!!

STOP! PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY. MAKE SURE YOU HAVE ALL THE PARTS AND HARDWARE AS IDENTIFIED ON THE PARTS LIST.

MISSING PARTS? DAMAGED PARTS? DON'T GO BACK TO THE RETAILER. WE CAN HELP YOU FASTER!

CALL OUR CUSTOMER SERVICE CENTER AT 1-800-416-3511 BETWEEN 9:00AM AND 5:00PM (EASTERN TIME) MONDAY THROUGH FRIDAY (CLOSED HOLIDAYS).

OR, VISIT OUR WEBSITE AT: www.shianco.com

TO EXPEDITE ANY FUTURE WARRANTY CLAIMS, RETAIN THE INSTRUCTION SHEET, WARRANTY CARD AND RECEIPT FOR FUTURE USE. YOU ARE ENCOURAGED TO REGISTER YOUR PURCHASE ON OUR WEBSITE AT www.shianco.com

FOR ADDITIONAL ONLINE VIDEO SUPPORT ON ASSEMBLY, TROUBLESHOOTING, AND CARE AND MAINTENANCE OF YOUR SHIANCO OUTDOOR FURNITURE, PLEASE VISIT OUR WEBSITE AT: www.shianco.com/support